

Protex™ N95 Particulate Respirator Model SR9520 (size M/L)

NIOSH Approved | TC-84A-9295

Featuring the Protex™ All-Day-Comfort™ System

Made by Shawmut Corporation, a world leader in advanced materials, the Protex™ SR9520 is a NIOSH approved N95 disposable respirator and meets NIOSH 42 CFR 84 N95 requirements for a minimum 95% filtration efficiency.

Designed, engineered, and manufactured in America, the cup-style Protex™ SR9520 respirator was created with patent pending ADC Protex All-Day-Comfort System® technology so you can count on it to fit better, protect better, and breathe easier all day long.

An N95 respirator that doesn't fit properly may not protect you. Protex™ N95s are designed to fit the widest range of face sizes and shapes and have received Fit Capability scores of up to 97% when tested against the ASTM F3407-20 Respirator Fit Capability (RFC) standard.



The Protex™
All-Day-Comfort™
System

Get Protex™ ADC™ for Advanced Protection and Comfort

The Protex™ ADC™ combines a unique soft but strong inner layer, incredibly lightweight but highly efficient and effective inner filtration layer, high-sealing viscoelastic nose foam, and expanded force curve elastic head straps for a secure but comfortable seal.

- **MORE SECURE FIT** – Protex™ N95s are designed to fit a wider range of face shapes and sizes. And a better fit means better performance: Protex™ N95s remove more than 95% of all 0.3+ micron particles.
- **BEST-IN-CLASS BREATHABILITY** – Proprietary Shawmut MB™ filtering technology exceeds NIOSH N95 standards while delivering better breathability and cooler, fresher air inside the cup.
- **ALL-DAY COMFORT** – Protex™ N95s feature softer, flanged edges that provide a more comfortable fit with less pressure on your face.
- **LESS EYEGLOSS FOGGING** – When formed around your nose and worn properly, the unique viscoelastic nose foam and aluminum nose clip reduce eyeglass fogging for better visibility.



PRODUCT DETAILS

Protex™ N95 Particulate Respirator Model SR9520

Style: Molded cup, non-valve

Size: Medium/Large

Color: White with yellow straps

Dimensions: 5.61" (width) x 4.8" (height) x 1.91" (depth)

Weight: 0.3 oz per respirator

Packaging: 20 N95s/box, 12 boxes/case

Compliance: NIOSH 42 CFR 84, TC-84A-9295

UPC: Box 850026398014, Case 00850026398021

Country of Origin: Made in USA

Type:

- Disposable filtering facepiece respirator
- N Series – Used in environments free of oil aerosols
- N95 – 95% against solid particulates and nonpetroleum based liquid aerosols at 0.3 microns

Technical Data:

- Box dimensions: 5.8125" (L) x 5" (W) x 8" (H)
- Box weight: 0.45 lbs.
- Case Dimensions:
18.125" (L) x 12.75" (W) x 16.25" (H)
- Case Weight: 6 lbs.

Contact Shawmut Today to Order Your Protex™ N95 Respirators

To Learn More or Place an Order:

PPESales@ShawmutCorporation.com
shawmutcorporation.com/health-safety/



Materials:

- Polypropylene filter and outer cover
- PET inner shell
- Elastic straps
- Aluminum nose clip
- Viscoelastic polyurethane nose foam
- All materials are PVC free
- Not made with natural rubber latex

Storage Conditions and Shelf Life:

Protex™ N95 particulate respirators have a standard shelf life of 5 years when respirators are stored in their original packaging within climatic conditions ranging from -4 °F (-20 °C) to +86 °F (+30 °C).

Use respirators before the “use by” date specified on each box.

Technical Assistance: 508-588-3300

Reorder Information

Part #	Size	QTY/Box	Boxes/Case
SR9520-12	M/L	20	12